

The diagram is structured as follows:

- Top Level:** A blue oval containing the text "SERVICE LIFE PREDICTION OF POLYMERIC SYSTEMS".
- Second Level:** A blue rectangle containing the text "Contributions from Individual Constituents" in green.
- Third Level:** A grey arrow pointing upwards from the "Metrology/Modeling" level to the "Contributions from Individual Constituents" level.
- Fourth Level:** A red line with three downward-pointing arrows, labeled "Metrology/Modeling" in red, connecting to three boxes below.
- Fifth Level:** Three blue boxes:
 - Left box: "Photoreactivity of TiO₂ Nanostructures" (text is blue).
 - Middle box: "Multi-scale Structure and Dispersion Measurements" (text is black, box has a yellow border, and a red checkmark is in the top-left corner).
 - Right box: "Nanomechanical Characterization" (text is black).

**SERVICE LIFE PREDICTION
OF POLYMERIC SYSTEMS**

**Contributions from
Individual Constituents**

Metrology/Modeling

Photoreactivity
of TiO₂
Nanostructures

✓
Multi-scale Structure
and Dispersion
Measurements


Nanomechanical
Characterization

Multi-scale Structure and Dispersion Measurements of Polymeric Coatings and Plastics



Li-Piin Sung

The Problem




- ❑ Almost all commercial polymeric construction products contain dispersed pigmentary and nanoscale particles.
- ❑ Poor particle dispersion adversely creates multi-scale structure in products, and affects **service life**, **appearance**, and **mechanical properties** of these products.
- ❑ Current industrial methods for assessing particle dispersion are **subjective, unreliable, and limited** to dilute suspensions of micron-size particles.
- ❑ Industrial needs: systematic understanding and efficient tools for **measuring** and **controlling** dispersion.





Dispersion Process

From DuPont Web site



Deficiency in any stage leads to **POOR DISPERSION CONTROL**

Dispersion impacts appearance, durability, functionality



Current Methods for Dispersion Measurements

- Fineness of grind gauge
 - Screening for micron-size particles
- Particle size by light scattering in very dilute state
 - Dilution shock, not equivalent to concentrated state
- Microscopy (SEM and TEM)
 - Limited sampling area, destructive, labor intensive
- Viscosity, optical density, color and tinting strength
 - Indirect, subjective

- non-quantitative, inadequate, inefficient-



What We Need!

✓ Understanding how particles/pigments **can be dispersed in a wide variety of media will be key to the adoption of many materials** by commercial markets

Characterize Dispersions

Understand Dispersion Mechanisms

Predict Dispersed State

Control dispersion

✓ **Characterizing multi-scale structure of the materials and relate to the performance/service life of the products.**

Heterogeneity ? at what length scale ?

Correlation and impact?



New Idea and Approach

- ❑ Using existing methods (microscopy and SANS..) and knowledge– with faster and better analysis methods/computer processing
- ❑ New instrument and capability (LS) in BFRL
- ❑ New approach and metrology
 - diffusive methods
 - backscattering
 - multi-wavelength application

Using photonic, acoustic, neutron, and other sources




Light Scattering Materials Characterization Laboratory

A308/226



LS-I




Forward Scattering



Reflection




LS-II



- **Static (5 nm – 10 mm)**
 - Time-averaged
- **Dynamic (1 nm – 5 mm)**
 - Time-dependent
- **Angular range (5° to 175°)**
- **Temperature (0° to 100° C)**


Measurable Materials Properties




- Spatial distribution of each constituent
- Interaction among each constituent
- Pigment/nanoparticle cluster size and dispersion

- Bulk/surface morphology
- Nano-/Microstructure
- Appearance (gloss & color)

LS-II



LS-I




Technical Approach -Research Objectives

- Develop **non-invasive, quantitative, and scientific-based** metrologies for characterizing particle dispersion in suspensions and in solid polymeric films
- Relate these dispersion properties to the appearance and service life of polymeric materials.
→ **"What dispersion state" gives "best" performance.**
- Establish **measurement protocols** for quantitatively measuring particle dispersion in suspensions and coatings.




Dispersion Project Organization



Working with Xiaohong Gu, Stephanie Watson, Aaron Forster, and Tinh Nguyen

Measurement Organization

In suspensions




Light scattering
Neutron scattering


← Tools →

In film and bulk


(before and after UV degradation)



Microscopy (LSCM, ESEM)
Light scattering
Neutron scattering
Depth profile sensitive tools



Results Generated: Gantt chart




Refine and improve current measurement techniques and advance data analysis

***: Need new high power laser/light source, detector, and optics**
\$: Invest on new instrumentation



Multi-Scale Characterization Techniques




For Bulk/Surface Morphology, Microstructure and Dispersion




Particle Dispersion Characterization - Scattering Metrology-

Structural Properties





Static and Dynamic

- ✓ Cluster Size & Shape
- ✓ Cluster-Cluster Interactions
- ✓ Morphology
- ✓ Spatial Distribution



Metrology


- ❑ Angular-resolved static & dynamic light scattering (SLS & DLS)
- ❑ Ultra-small & small-angle neutron scattering (USANS & SANS)
- ❑ Ultra-small & small-angle X-ray scattering (USAXS & SAXS)




Cluster Size Characterization of TiO₂ Particles in Various Chemical Assays

DLS


Three chemical Assays



Three particle sizes & surface treatments





Study the correlation of “*particle size, types, surface treatment*” to photoreactivity of TiO₂ particles




Size and Dispersion of Pigment Clusters



LSCM & SANS



3D reconstruction






**Topographic
analysis**



Pigment Dispersion in Polymer Coatings

- different media, different processing -




2 μm




Pigmented epoxy, latex coatings

Small Angle Light Scattering (SALS) from Latex -TiO₂ Coatings


0 %




17 %



2.5 %



17 %
larger
pigment






Optical scattering profiles reveal different structures in latex coatings

Small-Angle Light Scattering Study of UV-degraded PVDF Coatings




Initial

After 6 months-UV


PVDF/PMMA (100/0)



PVDF/PMMA (60/40)



0.5 μm^{-1}




Diffuse Scattering from Weathered Surfaces


Optical scattering

FL


Masked





LSCM




Masked



Exposed




Exposed



Specular intensity ↓ ; diffuse scattering ↑

Results Generated: Gantt chart



Refine and improve current measurement techniques and advance data analysis

***: Need new high power laser/light source, detector, and optics**
\$: Invest on new instrumentation



Impact

- ❑ Provide a unique and critical understanding of the particle dispersion in polymeric systems, one of the key components in future **pigment/nanoparticle** products and technologies.
- ❑ **Optimize** the pigment dispersion in coatings to achieve best performance, significantly **reduce the costs** associated with materials and production process.
- ❑ Provide in-depth knowledge in **dispersion mechanism** to industry for production and improve appearance and service life performances

